


TOOLS & MATERIALS

TILE SPACING & LEVELING




Ubertile Leveling System

LEVEL AND SPACE IN 1 STEP



Spread mortar and place tile




Insert levelling base



Apply cap and tighten




Allow mortar to cure



Strike base in the direction of the grout

Uber Leveling System


Level and space your tiles in one step.



Mandrel


Shield

Part Number	Style	Joint Size & Profile	Pack Size
303-42560-3	Mandrel (Reusable)		50 pcs
303-44653-8	Clear Tile Shield (Optional and Reusable) <i>(For use on delicate surfaces like polished tile)</i>		100 pcs



Leveling Spacer
1.5mm

Grout Joint	Part Number	Style	Joint Size & Profile	Pack Size
1.5 mm 1/16"	303-42562-3	Leveling Spacer	1.5mm Cross	100 pcs
	303-42562-3Z	Leveling Spacer	1.5mm Cross	4000 pcs
	303-42563-8	Leveling Spacer	1.5mm Tee	100 pcs
	303-42563-8Z	Leveling Spacer	1.5mm Tee	4000 pcs
	303-42561-8	Leveling Spacer	1.5mm Straight	100 pcs
	303-42561-8Z	Leveling Spacer	1.5mm Straight	4000 pcs



Leveling Spacer
3mm

Grout Joint	Part Number	Style	Joint Size & Profile	Pack Size
3 mm 1/8"	303-43098-1	Leveling Spacer	3mm Cross	100 pcs
	303-43098-1Z	Leveling Spacer	3mm Cross	4000 pcs
	303-43099-9	Leveling Spacer	3mm Tee	100 pcs
	303-43099-9Z	Leveling Spacer	3mm Tee	4000 pcs
	303-43097-3	Leveling Spacer	3mm Straight	100 pcs
	303-43097-3Z	Leveling Spacer	3mm Straight	4000 pcs

SPACER CALCULATOR

	When Used in Between	When Used On the Edge	
Tile Size	Spacers Required	÷	<i>To calculate edge pieces required, divide the linear feet of each space to be tiled by the number in Red.</i>
12" x 12"	4 bases per sq/ft	1	
12" x 24"	2 bases per sq/ft	1.5	
24" x 24"	1 bases per sq/ft	2	

*These calculations are estimates & spacer requirements may vary